

Scientific calculator

Please read carefully before use and safe keeping, for inspection

Before getting started...

Modes

Before starting a calculation, you must first enter the correct mode as indicated in the table below.

To perform this type of calculation:	Perform this key operation:	To enter this mode:
Basic arithmetic calculations	MODE 1	COMP
Standard deviation	MODE 2	SD
Regression calculations	MODE 3	REG

- Pressing the MODE key more than once displays additional setup screens. Setup screens are described in the sections of this manual where they are actually used to change the calculator setup.
- In this manual, the name of the mode you need to enter in order to perform the calculations being described is indicated in the main title of each section.

Example: **Statistical Calculations** SD REG

Note!

- To return the calculation mode and setup to the initial defaults shown below, press MODE 2 (Mode) 1 .
- Calculation Mode: COMP
- Angle Unit: Deg
- Exponential Display Format: Norm 1
- Fraction Display Format: a/b
- Decimal Point Character: Dot
- Mode indicators appear in the upper part of the display.
- Be sure to check the current calculation mode (SD, REG, COMP) and angle unit setting (Deg, Rad, Gra) before beginning a calculation.

Multi-statements

A multi-statement is an expression that is made up of two or more smaller expressions, which are joined using a colon (:).

- Example: To add 2+3 and then multiply the result by 4

2 + 3 = 5 $\text{Ans} \times 4$ = 20

Exponential Display Formats

This calculator can display up to 10 digits. Larger values are automatically displayed using exponential notation. In the case of decimal values, you can select between two formats that determine at what point exponential notation is used.

- To change the exponential display format, press the MODE key a number of times until you reach the exponential display format setup screen shown below.

Fix Sci Norm
1 2 3

- Press 3 . On the format selection screen that appears, press 1 to select Norm 1 or 2 for Norm 2.

Norm 1

With Norm 1, exponential notation is automatically used for integer values with more than 10 digits and decimal values with more than two decimal places.

Norm 2

With Norm 2, exponential notation is automatically used for integer values with more than 10 digits and decimal values with more than nine decimal places.

- All of the examples in this manual show calculation results using the Norm 1 format.

Decimal Point and Separator Symbols

You can use the display setup (Disp) screen to specify the symbols you want for the decimal point and 3-digit separator.

- To change the decimal point and separator symbol setting, press the MODE key a number of times until you reach the setup screen shown below.

Disp
1

- Display the selection screen.
 1 Disp
- Press the number key (1 or 2) that corresponds to the setting you want to use.
 1 (Dot): Period decimal point, comma separator
 2 (Comma): Comma decimal point, period separator

Initializing the Calculator

- Perform the following key operation when you want to initialize the calculation mode and setup, and clear re-play memory and variables.
 SHIFT CLR 3 (All) =

Basic Calculations (COMP)

Arithmetic Calculations

Use the MODE key to enter the COMP Mode when you want to perform basic calculations.
COMP MODE 1

- Negative values inside of calculations must be enclosed within parentheses. For details, see "Order of Operations."
- It is not necessary to enclose a negative exponent within parentheses.
 $\sin 2.34 \times 10^{-5} \rightarrow \text{sin } 2.34 \text{ EXP } (-) 5$
- Example 1: $3 \times (5 \times 10^{-9}) = 1.5 \times 10^{-8}$
 $3 \times 5 \text{ EXP } (-) 9 =$
- Example 2: $5 \times (9 + 7) = 80$ $5 \times (9 + 7) =$
- You can skip all OPN operations before = .

Fraction Operations

Fraction Calculations

- Values are displayed in decimal format automatically whenever the total number of digits of a fractional value (integer+numerator+denominator+separator marks) exceeds 10.
- Example 1: $\frac{2}{3} + \frac{1}{5} = \frac{13}{15}$
 $2 \text{ a/b } 3 + 1 \text{ a/b } 5 =$ 13 15
- Example 2: $3 \frac{1}{4} + 1 \frac{2}{3} = 4 \frac{11}{12}$
 $3 \text{ a/b } 1 \text{ a/b } 4 + 1 \text{ a/b } 2 \text{ a/b } 3 =$ 4 11 12
- Example 3: $\frac{3}{4} = \frac{1}{2}$ $2 \text{ a/b } 4 =$
- Example 4: $\frac{1}{2} + 1.6 = 2.1$ $1 \text{ a/b } 2 + 1.6 =$

- Results of calculations that mix fraction and decimal values are always decimal.

Decimal \leftrightarrow Fraction Conversion

- Use the operation shown below to convert calculation results between decimal values and fraction values.
- Note that conversion can take as long as two seconds to perform.

- Example 1: $2.75 = 2 \frac{3}{4}$ (Decimal \rightarrow Fraction)
 $2.75 \text{ a/b } =$ 2 3 4
 $= \frac{11}{4}$ $\text{a/b } \text{d/c} =$ 11 4
- Example 2: $\frac{1}{2} \leftrightarrow 0.5$ (Fraction \leftrightarrow Decimal)
 $1 \text{ a/b } 2 =$ 1 2
 $\text{a/b } =$ 0.5
 $\text{a/b } =$ 1 2

Mixed Fraction \leftrightarrow Improper Fraction Conversion

- Example: $1 \frac{2}{3} \leftrightarrow \frac{5}{3}$
 $1 \text{ a/b } 2 \text{ a/b } 3 =$ 1 2 3
 $\text{a/b } \text{d/c} =$ 5 3
 $\text{a/b } \text{d/c} =$ 1 2 3

- You can use the display setup (Disp) screen to specify the display format when a fraction calculation result is greater than one.
- To change the fraction display format, press the MODE key a number of times until you reach the setup screen shown below.

Disp
1

- Display the selection screen.
 1 Disp
- Press the number key (1 or 2) that corresponds to the setting you want to use.
 1 (a/b): Mixed fraction
 2 (d/c): Improper fraction
- An error occurs if you try to input a mixed fraction while the d/c display format is selected.

Degrees, Minutes, Seconds Calculations

- You can perform sexagesimal calculations using degrees (hours), minutes, and seconds, and convert between sexagesimal and decimal values.
- Example 1: To convert the decimal value 2.258 to a sexagesimal value and then back to a decimal value
 $2.258 \text{ a/b } =$ 2 258
 $\text{a/b } \text{d/c} =$ 2°15'28.8
 $\text{a/b } =$ 2.258
- Example 2: To perform the following calculation:
 $12^{\circ}34'56'' \times 3.45$
 $12 \text{ a/b } 34 \text{ a/b } 56 \text{ a/b } \times 3.45 =$ 43°24'31.2

FIX, SCI, RND

- To change the settings for the number of decimal places, the number of significant digits, or the exponential display format, press the MODE key a number of times until you reach the setup screen shown below.

Fix Sci Norm
1 2 3

- Press the number key (1 , 2 , or 3) that corresponds to the setup item you want to change.
 1 (Fix): Number of decimal places
 2 (Sci): Number of significant digits
 3 (Norm): Exponential display format

- Example 1: $200 \div 7 \times 14 =$
 $200 \text{ a/b } 7 \text{ a/b } \times 14 =$ 400.
- (Specifies three decimal places.) $\text{MODE} \dots \text{1}$ (Fix) 3 $\text{a/b } 400.000$
- (Internal calculation continues using 12 digits.) $200 \text{ a/b } 7 =$ 28.571
 $\times 14 =$ 400.000

The following performs the same calculation using the specified number of decimal places.

- $200 \text{ a/b } 7 =$ 28.571
- (Internal rounding) $\text{a/b } \text{RND} =$ 28.571
 $\times 14 =$ 399.994
- Press $\text{MODE} \dots \text{3}$ (Norm) 1 to clear the Fix specification.
- Example 2: $1 \div 3$, displaying result with two significant digits (Sci 2)
 $\text{MODE} \dots \text{2}$ (Sci) 2 $\text{a/b } 1 \text{ a/b } 3 =$ 3.3⁻⁰¹
- Press $\text{MODE} \dots \text{3}$ (Norm) 1 to clear the Sci specification.

Memory Calculations (COMP)

Use the MODE key to enter the COMP Mode when you want to perform a calculation using memory.
COMP MODE 1

Independent Memory

- Values can be input directly into memory, added to memory, or subtracted from memory. Independent memory is convenient for calculating cumulative totals.
- Independent memory uses the same memory area as variable M.
- To clear independent memory (M), input 0 SHIFT STO M (M+).
- Example:
 $23 + 9 = 32$ $23 \text{ a/b } 9 \text{ a/b } \text{STO } \text{M}$ (M+)
 $53 - 6 = 47$ $53 \text{ a/b } 6 \text{ a/b } \text{M} +$
 $-) 45 \times 2 = 90$ $45 \text{ a/b } 2 \text{ a/b } \text{M} =$
(Total) -11 $\text{RCL } \text{M}$ (M+)

Variables

- There are nine variables (A through F, M, X and Y), which can be used to store data, constants, results, and other values.
- Use the following operation to delete data assigned to a particular variable: 0 SHIFT STO A . This operation deletes the data assigned to variable A.
- Perform the following key operation when you want to clear the values assigned to all of the variables.
 SHIFT CLR 1 (Mcl) =

- Example: $193.2 \div 23 = 8.4$
 $193.2 \div 28 = 6.9$
 $193.2 \text{ a/b } 23 \text{ a/b } \text{a/b } 28 \text{ a/b } =$
 $\text{a/b } \text{a/b } \text{a/b } =$

Scientific Function Calculations (COMP)

Use the MODE key to enter the COMP Mode when you want to perform scientific function calculations.
COMP MODE 1

- Certain types of calculations may take a long time to complete.
- Wait for the result to appear on the display before starting the next calculation.
- $\pi = 3.14159265359$

Trigonometric/Inverse Trigonometric Functions

- To change the default angle unit (degrees, radians, grads), press the MODE key a number of times until you reach the angle unit setup screen shown below.
- Press the number key (1 , 2 , or 3) that corresponds to the angle unit you want to use.
($90^{\circ} = \frac{\pi}{2}$ radians = 100 grads)
- Example 1: $\sin 63^{\circ}52'41'' = 0.897859012$
 $\text{MODE} \dots \text{1}$ (Deg)
 $\text{a/b } 63 \text{ a/b } 52 \text{ a/b } 41 \text{ a/b } =$

- **Example 2:** $\cos\left(\frac{\pi}{3} \text{ rad}\right) = 0.5$
MODE \rightarrow 2 (Rad) \rightarrow COS \rightarrow 3 \rightarrow 0 \rightarrow 5 \rightarrow =
- **Example 3:** $\cos^{-1}\frac{\sqrt{2}}{2} = 0.25 \pi \text{ (rad)} = \frac{\pi}{4} \text{ (rad)}$
MODE \rightarrow 2 (Rad) \rightarrow 2ND \rightarrow COS \rightarrow 2 \rightarrow 2 \rightarrow 2 \rightarrow 2 \rightarrow = \rightarrow 2ND \rightarrow ANS \rightarrow 2ND \rightarrow =
- **Example 4:** $\tan^{-1} 0.741 = 36.53844577^\circ$
MODE \rightarrow 1 (Deg) \rightarrow 2ND \rightarrow TAN \rightarrow 0 \rightarrow 7 \rightarrow 4 \rightarrow 1 \rightarrow =

Hyperbolic/Inverse Hyperbolic Functions

- **Example 1:** $\sinh 3.6 = 18.28545536$ \rightarrow 3.6 \rightarrow =
- **Example 2:** $\sinh^{-1} 30 = 4.094622224$ \rightarrow 30 \rightarrow =

Common and Natural Logarithms/Antilogarithms

- **Example 1:** $\log 1.23 = 0.089905111$ \rightarrow 1.23 \rightarrow =
- **Example 2:** $\ln 90 (= \log_e 90) = 4.49980967$ \rightarrow 90 \rightarrow =
- $\ln e = 1$ \rightarrow 2ND \rightarrow LN \rightarrow =
- **Example 3:** $e^{10} = 22026.46579$ \rightarrow 10 \rightarrow =
- **Example 4:** $10^{1.5} = 31.6227766$ \rightarrow 1.5 \rightarrow =
- **Example 5:** $2^{-3} = 0.125$ \rightarrow 2 \rightarrow 3 \rightarrow =
- **Example 6:** $(-2)^4 = 16$ \rightarrow 2 \rightarrow 4 \rightarrow =
- Negative values inside of calculations must be enclosed within parentheses. For details, see "Order of Operations."

Square Roots, Cube Roots, Roots, Squares, Cubes, Reciprocals, Factorials, Random Numbers, π , and Permutation/Combination

- **Example 1:** $\sqrt{2+3 \times 5} = 5.287196909$ \rightarrow 2 \rightarrow + \rightarrow 3 \rightarrow \times \rightarrow 5 \rightarrow =
- **Example 2:** $\sqrt[3]{5+3 \times 27} = -1.290024053$ \rightarrow 5 \rightarrow + \rightarrow 3 \rightarrow \times \rightarrow 27 \rightarrow =
- **Example 3:** $\sqrt[7]{123} (= 123^{1/7}) = 1.988647795$ \rightarrow 123 \rightarrow =
- **Example 4:** $123 + 30^2 = 1023$ \rightarrow 123 \rightarrow + \rightarrow 30 \rightarrow =
- **Example 5:** $12^3 = 1728$ \rightarrow 12 \rightarrow =
- **Example 6:** $\frac{1}{\frac{1}{3} - \frac{1}{4}} = 12$ \rightarrow 3 \rightarrow 1 \rightarrow 4 \rightarrow =
- **Example 7:** $8! = 40320$ \rightarrow 8 \rightarrow =
- **Example 8:** To generate a random number between 0.000 and 0.999
(The above value is a sample only. Results differ each time.) \rightarrow 0.664
- **Example 9:** $3\pi = 9.424777961$ \rightarrow 3 \rightarrow =
- **Example 10:** To determine how many different 4-digit values can be produced using the numbers 1 through 7
• Numbers cannot be duplicated within the same 4-digit value (1234 is allowed, but 1123 is not). (840)
- **Example 11:** To determine how many different 4-member groups can be organized in a group of 10 individuals (210)

Angle Unit Conversion

- Press \rightarrow to display the following menu.

D	R	G
1	2	3

- Pressing 1, 2, or 3 converts the displayed value to the corresponding angle unit.

- **Example:** To convert 4.25 radians to degrees

MODE \rightarrow 1 (Deg) \rightarrow 4.25 \rightarrow = 243.5070629

Coordinate Conversion-(Pol (x, y), Rec (r, θ))

- Calculation results are automatically assigned to variables E and F.

- **Example 1:** To convert polar coordinates ($r=2$, $\theta=60^\circ$) to rectangular coordinates (x, y) (Deg)

x = 1 \rightarrow 2 \rightarrow 60 \rightarrow =
y = 1.732050808

- Press \rightarrow to display the value of x, or \rightarrow to display the value of y.

- **Example 2:** To convert rectangular coordinates (1, $\sqrt{3}$) to polar coordinates (r, θ) (Rad)

r = 2 \rightarrow 1 \rightarrow 3 \rightarrow =
 $\theta = 1.047197551$

- Press \rightarrow to display the value of r, or \rightarrow to display the value of θ .

Engineering Notation Calculations

- **Example 1:** To convert 56,088 meters to kilometers
 $\rightarrow 56.088 \times 10^3$ 56088 \rightarrow =
- **Example 2:** To convert 0.08125 grams to milligrams
 $\rightarrow 81.25 \times 10^{-3}$ 0.08125 \rightarrow =

Statistical Calculations

Standard Deviation

Use the \rightarrow key to enter the SD Mode when you want to perform statistical calculations using standard deviation.

SD \rightarrow =

- In the SD Mode and REG Mode, the \rightarrow key operates as the \rightarrow key.
- Always start data input with \rightarrow (Sci) \rightarrow to clear statistical memory.
- Input data using the key sequence shown below.
- Input data is used to calculate values for n , Σx , Σx^2 , \bar{x} , σ_n and σ_{n-1} , which you can recall using the key operations noted nearby.

To recall this type of value:	Perform this key operation:
Σx^2	\rightarrow 1
Σx	\rightarrow 2
n	\rightarrow 3
\bar{x}	\rightarrow 1
σ_n	\rightarrow 2
σ_{n-1}	\rightarrow 3

- **Example:** To calculate σ_{n-1} , σ_n , \bar{x} , n , Σx , and Σx^2 for the following data: 55, 54, 51, 55, 53, 53, 54, 52

In the SD Mode:

\rightarrow (Sci) \rightarrow (Stat clear)

55 \rightarrow 54 \rightarrow 51 \rightarrow 55 \rightarrow 53 \rightarrow 53 \rightarrow 54 \rightarrow 52 \rightarrow =

Each time you press \rightarrow to register your input, the number of data input up to that point is indicated on the display (n value).

54 \rightarrow 51 \rightarrow 55 \rightarrow 53 \rightarrow 53 \rightarrow 54 \rightarrow 52 \rightarrow =

Sample Standard Deviation (σ_{n-1}) = 1.407885953 \rightarrow 3 \rightarrow =
Population Standard Deviation (σ_n) = 1.316956719 \rightarrow 2 \rightarrow =
Arithmetic Mean (\bar{x}) = 53.375 \rightarrow 1 \rightarrow =
Number of Data (n) = 8 \rightarrow 3 \rightarrow =
Sum of Values (Σx) = 427 \rightarrow 2 \rightarrow =
Sum of Squares of Values (Σx^2) = 22805 \rightarrow 1 \rightarrow =

Regression Calculations

Use the \rightarrow key to enter the REG Mode when you want to perform statistical calculations using regression.

REG \rightarrow =

- In the SD Mode and REG Mode, the \rightarrow key operates as the \rightarrow key.
- Entering the REG Mode displays screens like the ones shown below.

Lin	Log	Exp	-
1	2	3	
\rightarrow \rightarrow \rightarrow			
-Pwr	Inv	Quad	
1	2	3	

- Press the number key (1, 2, or 3) that corresponds to the type of regression you want to use.

- 1 (Lin): Linear regression
- 2 (Log): Logarithmic regression
- 3 (Exp): Exponential regression
- 1 (Pwr): Power regression
- 2 (Inv): Inverse regression
- 3 (Quad): Quadratic regression

- Always start data input with \rightarrow (Sci) \rightarrow to clear statistical memory.

- Input data using the key sequence shown below.

- The values produced by a regression calculation depend on the values input, and results can be recalled using the key operations shown in the table below.

To recall this type of value:	Perform this key operation:
Σx^2	\rightarrow 1
Σx	\rightarrow 2
n	\rightarrow 3
Σy^2	\rightarrow 1
Σy	\rightarrow 2
Σxy	\rightarrow 3
\bar{x}	\rightarrow 1
$x\sigma_n$	\rightarrow 2
$x\sigma_{n-1}$	\rightarrow 3
\bar{y}	\rightarrow 1
$y\sigma_n$	\rightarrow 2
$y\sigma_{n-1}$	\rightarrow 3
Regression coefficient A	\rightarrow 1
Regression coefficient B	\rightarrow 2

Regression calculation other than quadratic regression

Correlation coefficient r	\rightarrow 3
\bar{x}	\rightarrow 1
\bar{y}	\rightarrow 2

- The following table shows the key operations you should use to recall results in the case of quadratic regression.

To recall this type of value:	Perform this key operation:
Σx^3	\rightarrow 1
$\Sigma x^2 y$	\rightarrow 2
Σx^4	\rightarrow 3
Regression coefficient C	\rightarrow 3
\bar{x}_1	\rightarrow 1
\bar{x}_2	\rightarrow 2
\bar{y}	\rightarrow 3

- The values in the above tables can be used inside of expressions the same way you use variables.

Linear Regression

- The regression formula for linear regression is:
 $y = A + Bx$.

- **Example:** Atmospheric Pressure vs. Temperature

Temperature	Atmospheric Pressure
10°C	1003 hPa
15°C	1005 hPa
20°C	1010 hPa
25°C	1011 hPa
30°C	1014 hPa

Perform linear regression to determine the regression formula terms and correlation coefficient for the data nearby. Next, use the regression formula to estimate atmospheric pressure at -5°C and temperature at 1000 hPa. Finally, calculate the coefficient of determination (r^2) and sample covariance ($\Sigma xy - n \cdot \bar{x} \cdot \bar{y}$).

In the REG Mode:

1 (Lin) \rightarrow (Sci) \rightarrow (Stat clear)

10 \rightarrow 1003 \rightarrow 25 \rightarrow 1011 \rightarrow =

Each time you press \rightarrow to register your input, the number of data input up to that point is indicated on the display (n value).

15 \rightarrow 1005 \rightarrow 20 \rightarrow 1010 \rightarrow 30 \rightarrow 1014 \rightarrow =

Regression Coefficient A = 997.4

Regression Coefficient B = 0.56

Correlation Coefficient r = 0.982607368

Atmospheric Pressure at -5°C = 994.6

Temperature at 1000 hPa = 4.642857143

Coefficient of Determination = 0.965517241

Sample Covariance = 35

Logarithmic, Exponential, Power, and Inverse Regression

- Use the same key operations as linear regression to recall results for these types of regression.
- The following shows the regression formulas for each type of regression.

Logarithmic Regression	$y = A + B \cdot \ln x$
Exponential Regression	$y = A \cdot e^{Bx}$ ($\ln y = \ln A + Bx$)
Power Regression	$y = A \cdot x^B$ ($\ln y = \ln A + B \ln x$)
Inverse Regression	$y = A + B \cdot 1/x$

Quadratic Regression

- The regression formula for quadratic regression is:
 $y = A + Bx + Cx^2$.

- **Example:**

x_i	y_i
29	1.6
50	23.5
74	38.0
103	46.4
118	48.0

Perform quadratic regression to determine the regression formula terms for the data nearby. Next, use the regression formula to estimate the values for \hat{y} (estimated value of y) for $x_i = 16$ and \hat{x} (estimated value of x) for $y_i = 20$.

In the REG Mode:

3 (Quad) \rightarrow (Sci) \rightarrow (Stat clear)

29 \rightarrow 1.6 \rightarrow 50 \rightarrow 23.5 \rightarrow 74 \rightarrow 38.0 \rightarrow 103 \rightarrow 46.4 \rightarrow 118 \rightarrow 48.0 \rightarrow =

Regression Coefficient A = -35.59856934 \rightarrow 1 \rightarrow =

Regression Coefficient B = 1.495939413 \rightarrow 2 \rightarrow =

Regression Coefficient C = -6.71629667 $\times 10^{-3}$ \rightarrow 3 \rightarrow =

\hat{y} when x_i is 16 = -13.38291067 \rightarrow 16 \rightarrow =

\hat{x} when y_i is 20 = 47.14556728 \rightarrow 20 \rightarrow =

\hat{x}_2 when y_i is 20 = 175.5872105 \rightarrow 20 \rightarrow =